



Alcatel 4200

Analogue Handset User Guide



Making / Receiving Calls

To make an Internal call	Dial the Extension Number
To make an External call	Dial 9 and then the Telephone Number
To answer a call	Lift the handset

Transferring / Holding Calls

To hold a call	Press R (Recall)
To retrieve a held call	Press R (Recall)
To transfer a call	Press R (Recall) then the Extension No then hang up
To cancel transfer	Press R (Recall) then 3

Speed Dials

To use Speed Dials	Dial the Speed Dial number (7000 - 7999)
--------------------	---

System Features

To activate Call Back	Dial the Extension Number R (Recall) and press #
To cancel Call Back	Press R (Recall) then #
Redial	Press Redial
To have a conference call	While on 1 st call dial the 2 nd person you wish to include and when they answer dial R (Recall) 50
Group pick-up	Dial 14
Individual call pick-up	Dial 13 and the relevant Extension Number
To park a call	Press R (Recall) then Dial 12 (Store a call on an extension)
To retrieve a parked call	Dial 12 and then the Extension Number that the call is parked on

Diverts

To Divert your calls	Dial 61 and the Extension Number you wish to divert to
To Divert on Busy	Dial 62 and the Extension Number you wish to divert to
To set a DND (Do Not Disturb)	Dial 63
To cancel all Diversions	Dial 60

Voicemail

To initialise your mailbox	Press 51 Enter your Mail Box Number (Extension Number) It will ask you to enter a 4 digit personal password (default 2222) Press # to confirm Say your name Press #
To record your message	Press 51 Enter your Mail Box Number (Extension Number) Press 3 Enter your 4 digit personal password Press 4 for Personal Options Press 1 to Change Greeting Press 4 to Record Greeting Press # to Confirm
Accessing your message	Press 51 Enter your Mail Box Number (Extension Number) Press 3 Enter your password – 2222 (default password) Press 1 to Listen to your message Press 2 to Archive Press 3 to erase your message
Accessing your message from Out with the office	Dial your DDI number When your message begins press * then # on your telephone Enter your mailbox number Enter your personal password Press 1 to listen to your message Press 2 to archive the message Press 3 to erase
To Activate your Voicemail	Dial 61 and then 51
To take your Voicemail off	Dial 60

Note: If you have a voicemail box, your calls will automatically go to voicemail after 6 rings.

G B Telecom (Scotland) Ltd Contacts

General Enquiries

Galamoor House
Netherdale
Galashiels
TD1 3EY

Telephone 01896 752607
Fax 01896 661308
E-mail enquires@gbtelecom.co.uk

Sales

Telephone 01896 661313
E-mail sales@gbtelecom.co.uk

Faults, Technical and Training

Telephone 01896 661319
E-mail support@gbtelecom.co.uk

Network

Telephone 01896 661317
E-mail network@gbtelecom.co.uk

Accounts

Telephone 01896 661303
E-mail accounts@gbtelecom.co.uk